

Seascans August 2013

DIGITAL OZONESONDE CHECKLIST

FLT#

HAR150804

INITIAL PREPARATION -7 DAYS BEFORE FLIGHT.

- DATE (LOCAL): 8/2/15
 INITIALS: JRN
 PUMP# (add x,y,z,R): 27 2 8724
- | | |
|--|--|
| 1. Run zero air 10 minutes <input checked="" type="checkbox"/> (✓) | 5. Bypass cell <input type="checkbox"/> (○) |
| 2. PUMP CURRENT: _____ | 6. Add 5-6cc cathode <input type="checkbox"/> (○) |
| 3. PUMP PRESSURE: _____ | 7. 30 MINUTES HI O ₂ <input type="checkbox"/> (○) |
| 4. ENSCI Press/vac: _____ | 8. 3 MINUTES NO O ₂ <input type="checkbox"/> (○) |
-
- | | |
|--|--|
| 9. DUMP CATHODE RINSE: _____ (✓) | 16. Run sonde for 10 minutes on NO O ₂ AIR: _____ (○) |
| 10. ADD 3.0 CC FRESH CATHODE # _____ | 17. Short the cell leads: _____ (○) |
| 11. ADD 1.5 CC ANODE SOLUTION: _____ (✓) | 18. Intake tube stored in sonde frame: _____ (○) |
| 12. RUN 10 MINUTES on NO O ₂ _____ (✓) | 19. Place Instrument inside plastic bag: _____ (○) |
| 13. RECORD CURRENT: BG = _____ μamps | 20. Store inside Styrofoam flight box: _____ (○) |
| 14. RUN 10 MINUTES on 5 μamps O ₂ _____ (✓) - then switch to NO O ₂ AIR. | |
| 15. RECORD: TIME TO DROP FROM 4 TO 1.5 μamps: _____ sec. | |

2-5 DAYS AFTER INITIAL PREP: REPLACE SOLUTIONS: DATE (LOCAL): 8/2/15

- | | |
|---|---|
| 1. Replace Cathode/Anode <input checked="" type="checkbox"/> (✓) | 6. RECORD TIME TO DROP FROM 4 TO 1.5 μamps: <u>25.38</u> sec |
| 2. RUN 5 MINS on NO O ₂ <input checked="" type="checkbox"/> (✓) | 7. RUN 5 MINS on NO O ₂ <input checked="" type="checkbox"/> (✓) |
| 3. RECORD CURRENT: <u>0.06</u> μamps | 8. Short cell leads <input checked="" type="checkbox"/> (✓) |
| 4. RUN 5 MINS on 5 μamps O ₂ <input checked="" type="checkbox"/> (✓) | 9. Store inside Styrofoam flight box: <input checked="" type="checkbox"/> (✓) |
| 5. Switch to NO O ₂ AIR | |

FLIGHT PREPARATION IN LAB.

DATE (LOCAL): 8/3/15
INITIALS: JRN

T100 FLOWRATE TIMES

ROOM TEMP (C): 17 °C ROOM RH (%): 53%
 Flowrate Correction: 1.1 (%)

FLOWRATE #1:	<u>25.03</u> sec
FLOWRATE #2:	<u>25.07</u> sec
FLOWRATE #3:	<u>24.97</u> sec
FLOWRATE #4:	<u>25.19</u> sec
FLOWRATE #5:	<u>24.94</u> sec
AVERAGE T100:	<u>25.04</u> sec

- | |
|---|
| 1. Cathode solution # or date written on bottle: <u>5/14/15</u> |
| 2. CHANGE CATHODE SOLUTION (3cc): <input checked="" type="checkbox"/> (✓) |
| 3. CHANGE ANODE SOLUTION (1.5cc): <input checked="" type="checkbox"/> (✓) (Yes/No) |
| 4. RUN ON NO O ₂ FOR 10 MINUTES: _____ (○) |
| 5. RECORD THE NO O ₂ BACKGRND#1: BG1 = <u>0.03</u> μamps |
| 6. RUN ON 5 microamps of O ₂ for 10 Minutes: <input checked="" type="checkbox"/> (✓) |
| 7. SWITCH TO NO O ₂ AIR. |
| 8. RECORD: THE TIME TO DROP FROM 4 TO 1.5 μamps: <u>29.07</u> sec |
| 9. RECORD: 5 - T100 FLOWRATE TIMES: |

DAY OF FLIGHT @ THE LAUNCH SITE.

FLIGHT NUMBER: _____
 GMT DATE (YYMMDD): _____ LOCAL DATE: _____
 GMT LAUNCH TIME: _____ LOCAL TIME: _____

Operator Initials: _____
 BALLOON SIZE: _____ Grams: TOTEX _____ Hwoyee _____ (✓ one)
 PAY-OFF-WEIGHT: _____ Grams: Burst Alt: _____ (km)

O₂ sn: _____ O₂ CELL BACKGROUND (μamps): _____
 O₂ Flowrate: _____ (sec) O₂ Flowrate Correction: _____ (%)

Radiosonde s/n: _____ Freq: _____ (MHz)

SURFACE PRES: _____ (hPa)
 SURFACE TEMP: _____ (C)
 SURFACE RH: _____ (%)

Sky Conditions: _____

REMARKS: _____